

Measure what you see

wave-scan 3 / wave-scan 3 dual



Operating Instructions

Table of Contents

1 Introduction	5
1.1 For Your Safety	6
1.1.1 Meaning of the Symbols	6
1.1.2 Warning - Possibility of Injuries	7
1.1.3 Warning - Severe Damage	8
1.1.4 Caution - Material Damage	9
1.1.5 Information - Device Usage	9
1.2 Disposal	10
1.3 Disclaimer	10
1.4 Copyright	10
1.5 Declarations	11
1.5.1 Declaration of Conformity (EU)	11
1.5.2 FCC Declaration (USA)	12
1.5.3 IC Declaration (Canada)	13
1.5.4 Japanese Declaration	13
1.6 Intended Use	14
2 System Description	15
2.1 Delivery Content	15
2.1.1 Transportation Case	15
2.1.2 Names and Functions of Parts	16
2.1.3 Accessories	17
2.2 Measurement Principle	17
2.2.1 Measurement of Waviness	18
2.2.2 Wavelength and Scales	18
2.2.3 Measurement of Dullness	19
2.2.4 Structure Spectrum	19
2.3 Desktop Software	20
2.3.1 Download	20
2.3.2 Installation	21
2.4 List of Documents	22
3 Getting Started	23
3.1 System Diagram	23
3.2 Powering the Instrument	24
3.2.1 Rechargeable Battery Pack	24
3.2.2 Charging the Instrument	26
3.2.3 Battery Warning	27
3.2.4 Switching On	27
3.3 Attaching the Hand Strap	27
3.4 Using the Main Menu	28
3.5 Inclination Sensor	29
3.6 Starting Measurements	29
3.7 Testing the Instrument	30
4 Quick Measurements	31
4.1 Measuring	31
4.2 Initial Menu	31
4.3 Procedure	32

4.4	Results	33
4.5	Messages	33
4.6	Final Menu	34
5	Standard Measurements.....	35
5.1	Overview	35
5.2	Measuring	36
5.3	Standards	37
5.4	Test Series	38
5.5	Samples	38
5.5.1	Initial Menu.....	39
5.5.2	First Measurement.....	40
5.5.3	Final Menu	41
5.5.4	Next Measurement.....	42
5.6	Aborting.....	42
6	Organizer Measurements.....	43
6.1	Organizer Files.....	43
6.2	Organizer Process	44
6.3	Upload to Database	46
7	Browse Measurements.....	47
7.1	View Data	47
7.2	Delete Data.....	49
8	Configuration	51
8.1	Measurement Parameters.....	53
8.1.1	Scales	54
8.1.2	Statistics.....	55
8.1.3	Scan Length.....	56
8.1.4	Plausibility	56
8.1.5	Interrupt Statistics	58
8.1.6	Orientation Detection	58
8.2	WiFi Connection	59
8.3	System Information	61
8.4	Display Time.....	61
8.5	Checking Tiles.....	62
8.6	Factory Reset.....	63
8.7	Protect Configuration	64
8.8	Shutdown.....	65
9	Appendix.....	67
9.1	Application Hints.....	67
9.2	Cleaning Instructions	68
9.3	System Messages	70
9.4	Technical Data	74
9.5	Global Services.....	76
9.6	Service Points	77
	Index.....	79

1 Introduction

Dear customer,

thank you for having decided for a BYK-Gardner product. BYK-Gardner is committed to providing you with quality products and services. We offer complete system solutions to solve your problems in areas of color, appearance and physical properties. As the basis of our worldwide business, we strongly believe in total customer satisfaction. Therefore, in addition to our products, we offer VALUE-ADDED services:

- Technical Sales Force
- Technical & Application Support
- Application and Technical Seminars
- Repair & Certification Service

BYK-Gardner is part of the Altana Group and a direct subsidiary of BYK, the worldwide leader of additives for coatings and plastics. Together we offer complete and unique solutions for you, our customer.

Thank you for your trust and confidence. If there is anything we can do better to serve your needs, do not hesitate to let us know.

Your BYK-Gardner Team

www.byk-instruments.com

1.1 For Your Safety

Before operating the instrument the first time, please read the operating instructions and take particular notice of the safety instructions. If you use the instrument and the accessories properly, there are no hazards to fear.

This product is equipped with safety features. Nevertheless, read the safety instructions carefully and use the product only as described in these instructions to avoid accidental injury or damage.

No claims of product liability or warranty can be honored if the device is not operated in accordance with the operating instructions.

1.1.1 Meaning of the Symbols

Throughout this document the following symbols and terms are used.



WARNING

This symbol warns of the danger of injuries. The term **WARNING** warns of **severe** injuries and material damage. Different symbols can be used - if applicable.



CAUTION

This symbol warns of the danger of injuries. The term **CAUTION** warns of **slight** injuries or damage. Different symbols can be used - if applicable.



NOTICE

This symbol points out additional information – which can be important for the operation of the instrument.

1.1.2 Warning - Possibility of Injuries



CAUTION

Familiarization with safety instructions is necessary

Absence of knowledge of safety instructions threatens your health and can damage the instrument. Read the safety instructions before you use the instrument the first time.

The safety instructions are part of the delivery content. You find the safety instructions in the dedicated booklet enclosed to the instrument carrying case.

The safety instructions also include information about disposal, liability and copyright.



WARNING

Injuries possible due to defects and extraordinary loads

If safe operation can no longer be presumed, shut down the device and secure it against unintended operation.

The device must be presumed unsafe to operate:

- if visible damage is evident,
- if the instrument is no longer working,
- if it has been stored for long periods under adverse conditions or
- after harsh treatment during shipping.



WARNING

Safety advices for rechargeable battery packs

Do not crush or dismantle, do not heat or incinerate, do not immerse in any liquid, do not place in or near high temperature places or in direct sunlight. Batteries can explode or release harmful substances.

Ensure batteries have no short circuit on the contacts (for example due to damaged insulation). Metallic objects must not come in contact with the bare contacts. Immediately discontinue use if batteries appear abnormal in any way.

Use only the battery pack included with delivery. Use only the power supply included with delivery. Do not use battery pack or power supply for other devices.

**⚠ WARNING****Do not try to repair your instrument on your own**


Do not perform any repairs on the instrument. The measurement unit must be opened by BYK-Gardner authorized repair locations only.

Devices returned to BYK-Gardner for repairs or service / re-certification must be shipped **without** battery pack in the case / instrument.

**⚠ WARNING****Eye damage caused by illumination LEDs**

Looking into the illumination LEDs during measurement could harm your eyes. Do not look into the measurement aperture when the instrument is turned on - even if you assume a fault with the instrument.

The instrument is a class 1 laser product. To indicate the risks following label is placed on the housing and / or on the base of the instrument.



1.1.3 Warning - Severe Damage

**⚠ WARNING****Severe material damage**

The instrument consists of sensitive optical and electronic precision parts. Prevent it from being dropped, bumped or shaken!

Avoid exposure to continuous humidity and condensation. Avoid splashing with water, chemicals or other liquids.

Please use only accessories that are available for the unit.

Only devices meeting the requirements for low voltage safety may be connected to the USB interface.

The charger in the docking station is only to be used to charge the battery packs delivered with the instrument.

1.1.4 Caution - Material Damage



⚠ CAUTION

Material damage

Do not allow any foreign objects to get into the measurement opening.

Do not expose the unit to direct sunlight for extended periods of time. Do not store it in a hot or dusty environment. Use the instrument case for storage.

Rechargeable Li-Ion battery packs: Do not charge at temperatures below 0°C. The allowed temperature range is 10 to +40°C for operation and 0° to 60° for storage.

Do not use any acetone for cleaning the unit! The unit housing is resistant to many solvents. For cleaning you should use a soft, moist cloth. Excessive dirt and dust can be removed with ethanol or cleaning alcohol.

In case you intend not to use the instrument for a longer period of time, take out the batteries.

1.1.5 Information - Device Usage



NOTICE

Disconnecting from any Power Source

To disconnect the **instrument**: Remove the battery pack and / or the USB interface cable.

To disconnect the **docking station**: Disconnect the plug from the power supply and / or the USB interface cable.

To disconnect the **power supply**: Disconnect the power cable from the power supply and / or from mains socket.

Please make certain that the power supply plug is easily accessible. Use only the power supply included with delivery.



NOTICE

Using the instrument

You will find the technical data for all system components on the respective manufacturer's plates and in the section 'Technical Data'.



1.2 Disposal

Disused electrical equipment such as this instrument and its batteries must be professionally disposed. Do not dispose it in household garbage and make sure to observe the national law in your country.

1.3 Disclaimer

Exclusion of Liability

No liability other than as provided by law is assumed for direct or indirect damage sustained in association with the use of the instrument, the software or documentation.

BYK-Gardner precludes all liability claims if the usage described in "Intended Use" is disregarded. Any other usage than described in "Intended Use" is not according to the purpose of the instrument and leads to termination of liability claims.

[Intended Use](#) [► 14]

1.4 Copyright

Specific properties and structural characteristics of the instrument are intellectual property of BYK-Gardner. The copyright of this manual remains with BYK-Gardner.

This document must not be reproduced fully or in part, published or used for any other competitive purposes, no matter whether against payment or not, without prior written authorization from BYK-Gardner.

BYK-Gardner reserves the right to update the instrument, software and written documentation without prior notice.

© Copyright 2020 BYK-Gardner GmbH

All rights reserved

1.5 Declarations

1.5.1 Declaration of Conformity (EU)

Hereby,

BYK-Gardner GmbH

Lausitzer Strasse 8

D-82538 Geretsried

declares, that the products of type

- **wave-scan 3**
- **wave-scan 3 dual**

comply with the requirements of the following directives for Electromagnetic Compatibility (EC) of the European Union (EU):

- 2014/30/EU - Electromagnetic Compatibility
- 2014/35/EU - Low Voltage
- 2014/53/EU - Radio Equipment Directive (RED)

The following harmonized standards were applied:

- EN 60825-1:2007
- EN 61010-1:2010
- EN 61326-1:2013

Geretsried, November 13, 2019

A handwritten signature in black ink, appearing to read 'Frank R. Wagner', with a large, stylized loop at the end.

Frank R. Wagner
Managing Director

1.5.2 FCC Declaration (USA)

This equipment contains a radio module with FCC ID QPU8000.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF exposure statement (portable devices)

This device complies with the RF exposure SAR test exclusion requirements for portable devices, if a minimum separation distance (2 cm) to the antenna is kept. If the device is used and held correctly, the distance to the antenna will be maintained and the risk of human contact during normal operation is minimized.

1.5.3 IC Declaration (Canada)

This equipment contains a radio module with IC ID 4523A-SN8000.

This Class A digital apparatus complies with Canadian ICES-003.

This device complies with Industry Canada's license-exempt RSSs.

Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

1.5.4 Japanese Declaration

This equipment contains specified radio equipment that has been certified to the Technical Regulation Conformity Certification under the Japanese Radio Law.

MIC ID: R 006-000497



1.6 Intended Use

The **wave-scan 3** (7403) is designed to measure Orange Peel & Distinctness-of-Image (DOI) on high-gloss surfaces. The **wave-scan 3 dual** (7400) has additional LEDs to support an extended measurement range – it can also measure on semi-gloss surfaces.



By placing the base plate of the unit onto the surface, pressing the **Operate** button on the side and moving the instrument over the surface, it measures the properties of the surface and processes, stores and displays the measured data.

The instrument can be connected via USB or WiFi to a PC in order to read or write data. The capacitive display on the top allows an easy configuration and usage of the instrument.

2 System Description

The **wave-scan 3 / 3 dual** is a portable surface analyzer that measures Orange Peel and the Distinct of Image (DOI) on high-gloss and semi-gloss surfaces. It is operated by the **Operate** button on the left side and the touch-screen display on the top side. The **Operate** button is used to switch on the instrument and to trigger a measurement. The touch-screen display is used to select icons and functions directly.

2.1 Delivery Content

The systems wave-scan 3 and wave-scan 3dual come complete with: Measurement unit, docking station, external power supply unit with power connection line, 2 rechargeable Li-Ion battery packs, 2 USB cables, cover, test tile, certificate, safety and short instructions.

2.1.1 Transportation Case



The items listed below are contained in the packaging. Please contact BYK-Gardner if any item is missing or damaged.

1 Safety Instructions, Short Instructions and retraceable Certificate	5 Transportation case with padding
2 Measurement unit with protection cover and rechargeable battery pack #1	6 Docking station
3 Standard plate with cover – includes standard #1 and #2 to be measured	7 Internal charger with rechargeable battery pack #2
4 Below the plate: Hand strap, power cable and USB interface cables	8 Power supply

There is additional spare for the cables below the plate for the test tile(s). The interface cable USB type B/A is for connecting the docking station to a PC. The interface cable USB type C/A is for connecting the device to a PC.

2.1.2 Names and Functions of Parts

The basic system consists of the measurement unit and the docking station. The docking station is used to exchange data and to charge the rechargeable battery pack.



NOTICE

When the instrument is not in use, place it in the docking station. This way the rechargeable battery pack will be charged and the instrument will always be ready for measurements.

The measurement unit consist of the following parts.



1 Capacitive display	5 Insertion place for primary battery pack
2 Signal LED	6 Hand strap
3 USB connector for data communication	7 Operate button to turn device on / perform measurements
4 Protection cover	8 Measurement aperture and docking station connectors
	9 Reserve battery pack from docking station

The instrument comes with a protection cover. Remove it before operation and attach it after operation. Also attach the cover before placing the unit in the transport case.

The button **Operate** and the display are used to control the system. Pressing **Operate** turns the unit on and causes the instrument's dashboard (main menu) to be displayed. All settings within the menus are made by the display.

In measuring mode pressing the button **Operate** performs measurements. In configuration mode it has the same function as the symbol **Back**.

System operation is supported by an auto-diagnosis test, comments and error messages. Measurement values and comments appear in the display.

2.1.3 Accessories

For the measurement system following accessories and replacements can be ordered.

Measurement unit:

- **7400:** wave-scan dual
- **7403:** wave-scan

Accessories:


- **4831:** Software smart-process
Software for professional analysis and documentation of color and appearance.
- **7401:** Docking station
Incl. USB cable and power supply 100 - 240 V - self adapting.
- **7402:** Li-Ion battery pack
Rechargeable battery for automatic charge in the docking station.
- Checking tile replacement:
Please contact your local service department for replacement of your checking tile.
 - **7404:** Checking tile for wave-scan 3 dual
 - **7408:** Checking tile for wave-scan 3

To find your nearest local service department refer to:

- <https://www.byk-instruments.com/global-service-centers>

2.2 Measurement Principle


The wave-scan is the objective eye for a brilliant finish. It provides quality control and trouble shooting for class A surfaces.



Surface appearance changes with the size and distinctness of wavy structures. The wave-scan analyzes waviness intensity with 5 wavelength ranges (0.1 mm - 30 mm) and evaluates the brilliance of the surface. The results form a "structure spectrum" and help to analyze and optimize the surface quality based on material and / or process parameters.

2.2.1 Measurement of Waviness


The wave-scan simulates visual perception. Like our eyes, the instrument optically scans the wavy light / dark pattern. A laser point light source illuminates the specimen at a 60° angle and a detector measures the reflected light intensity at the equal but opposite angle.



The instrument is rolled across the surface and measures point by point the optical profile of the surface across a defined distance. The wave-scan analyzes the structures according to their size. In order to simulate the human eye's resolution at various distances, the measurement signal is divided into several ranges of wavelength using mathematical filter functions.

2.2.2 Wavelength and Scales

Standard scales for wavelength are the classic SW and LW and the modern W_a .. W_e .



These scales have following ranges:


- Shortwave (SW) = 0.3 .. 1.2 mm
- Longwave (LW) = 1.2 .. 12 mm
- W_a = 0.1 .. 0.3 mm
- W_b = 0.3 .. 1 mm

- $W_c = 1 \dots 3 \text{ mm}$
- $W_d = 3 \dots 10 \text{ mm}$
- $W_e = 10 \dots 30 \text{ mm}$

These scales (and many more) can be activated in the instrument.

2.2.3 Measurement of Dullness


Structures smaller than 0.1 mm influence visual perception, therefore the wave-scan uses a CCD camera to measure the diffused light caused by these fine structures.



This parameter is referred to as "dullness".

2.2.4 Structure Spectrum

The values of dullness and W_a to W_e form a complete "structure spectrum".



This allows a detailed analysis of orange peel and its influencing factors, being material or application parameters.

2.3 Desktop Software

All critical color and appearance parameters can be saved and analyzed with one software package, "smart-process". This includes the measurement of Orange Peel and Distinctness-of-Image (DOI) with the instruments of the wave-scan family.



NOTICE

You need "smart-chart" with version 7.1 or higher.

2.3.1 Download


For the wave-scan family the software is available as following package:

- **smart-process:** Offers the set-up of organizers for clear sample identification and a menu guided operation on the instrument.

To download the software package go to following web-site:

- www.byk-instruments.com/wave-scan

Via this link you can easily open and view the software package with your preferred browser application.



It is recommended to save the package on the hard drive of your PC before installation.

2.3.2 Installation




NOTICE

You need administrator privilege on the PC in order to install the software package.

To install the software package - provided as a ZIP archive:

1. Save the file on your hard drive into a new folder.
2. Extract the complete ZIP archive.
3. In the extracted folder, right mouse click on the file **install.exe**.
4. Select **Run as administrator**.
5. Follow the setup instructions on the screen.

Using the software you can create organizer files with complex measurement series and download to the instrument.



After upload of the measured data to the database in your PC you can use the software for data analysis and statistics.



NOTICE

After download and installation the software package can be used for **30 days** free trial. Thereafter, you need to register your software package. The standard delivery includes two PC licenses for the selected software package.

2.4 List of Documents

For the measurement system the following documentation is provided.

Document Type	Document No.	No. of Languages
Safety Instructions	301 200 082	24
Short Instructions	301 200 083	8
Operating Instructions	301 200 085	1

All documents can be downloaded from our website:

- <https://www.byk-instruments.com/manuals>

Alternative downloaded via product details pages:


- <https://www.byk-instruments.com/p/7400>
- <https://www.byk-instruments.com/p/7403>

3 Getting Started

Before operating the instrument for the first time, please read the operating manual completely and take particular notice of the safety instructions. Unpack the instrument and check the delivery for completeness - see [Delivery Content](#) [► 15].

3.1 System Diagram

The entire system consists of instrument, docking station and test tiles and software for data transfer and analysis.



To assemble the measurement system place the instrument in the docking station and power the docking station.

- Connect docking station with power supply **(1)**.
- Power is provided to the instrument by the rechargeable battery pack – charged in the docking station.
- The delivery comprises a second rechargeable battery pack – you can use one of them while recharging the other one.
- Place instrument in the docking station **(2)**.
- The docking station automatically charges the battery pack in the docking station and in the instrument.
- Connect docking station with PC via USB cable **(3)**.
- Download and install the software “smart-chart” **(4)**.
- Turn instrument on by pressing the **Operate** button.

The instrument switches off automatically, if not used. To switch it off manually, select **Configuration > Shutdown**.

3.2 Powering the Instrument

The measurement unit can be operated with the rechargeable battery pack included in the delivery. Depending on the specific brand, the capacity of the battery pack is sufficient for upto 1.000 measurements.

3.2.1 Rechargeable Battery Pack



To place the instrument in service, the rechargeable battery pack must be inserted until it locks in place. The second battery pack is inserted in the docking station. The battery pack can only be attached when it is in the correct position.



CAUTION

Do not remove the rechargeable battery pack while the instrument is switched on. Always perform regular **Shutdown** before opening the instrument's housing.



When inserting the rechargeable battery pack, ensure that its contacts are aligned with those of the instrument.



NOTICE

Using rechargeable battery packs

To ensure uniform utilization, the rechargeable battery packs should be exchanged regularly between instrument and docking station. The recommendation is a weekly exchange.

The rechargeable battery pack should be fully charged in regular intervals to maintain its full capacity. The recommendation is at least once every 6 months.

3.2.2 Charging the Instrument

The charging takes place via the docking station:

1. Connect the docking station to the power supply.
2. Remove the protection plate from the instrument.
3. Put the instrument into the docking station.

Both battery packs are charged. The battery pack in the docking station is charged faster than the one in the device.



Three charge LED indicate the current state:

- Left: Docking station is powered.
- Middle: Battery pack #1 in the instrument is charged.
- Right: Battery pack #2 in the docking station is charged.

For the charge LED following rules apply:

- LED pulsates red as long as the battery charge is < 15%.
- LED pulsates yellow as long as the battery charge is < 50%.
- LED pulsates green as long as the battery charge is < 90%.
- LED lights up in green when the battery charge is $\geq 90\%$.

With green LED light the device is fully charged and can be put in operation. Keep the device in the docking station as long as it is not in use.

3.2.3 Battery Warning

When the battery voltage falls below the required operating voltage in the course of operation, the following message appears on the display.



To ensure that the instrument is always ready for operation, it is recommended to have the second battery pack handy - especially when performing measurements in the field.

3.2.4 Switching On

The instrument is turned on via the **Operate** button on the left side. After turning on the instrument the display on the top shows the main menu.

The instrument is operated completely via the display and the **operate** button.

The instrument turns off automatically, if not used – see **Configuration > Display time**. For manual turn off select **Configuration > Shutdown**.

3.3 Attaching the Hand Strap

The instrument provides a mounting option for the safety wrist strap.



Use the hand strap as protection against dropping the instrument.

3.4 Using the Main Menu

The instrument comes with a capacitive display. To select the items on the screen you can tap with the finger on the display. Alternatively you can use a pen (sold separately). The pen should have a size of min. 6 mm in order to work on the display. For each main function a separate icon is available.



1 Quick check

Take a fast measurement using the default parameters.

2 Measure

Take measurements. Results are saved automatically.

3 Browse

View and delete measurement data.

4 Configuration

Change measurement parameters or instrument settings.

5 Organizer

Appears after downloading at least one organizer from "smart-chart".

Additional Symbols

On the top some additional symbols are displaying the current system status:

- **WiFi:** With upcoming firmware releases a wireless connection can be used in addition to USB.
- **Time:** Current system time - see **Configuration > Date / Time > Set time**.
- **Power:** Current charge level of battery pack in the device.

3.5 Inclination Sensor


The angle of holding the instrument is observed by the integrated sensor. Depending on the current angle the display is automatically flipped.



To flip the display back change the angle of holding until the sensor detects the difference and flips the display again.

3.6 Starting Measurements

You can directly start taking measurements. The instrument is working with default parameters. Select **Configuration > Measurement Parameters** to change these settings.




Details see [Measurement Parameters](#) [► 53].

3.7 Testing the Instrument

Due to the underlying measurement principle, no calibration of the instrument is required. It is recommended, however, to check the functionality of the instrument at regular intervals. The recommendation is once every 3 months. The checking tiles included with delivery are provided for this purpose.



These tiles are fix assigned to your instrument. Select **Measure > Standards** and select the checking tile which you want to measure. See [Checking Tiles](#) [▶ 62] for more details.



Place the instrument on the corresponding checking tile and perform a measurement. Your instrument measures correctly, if the measured date is within given range of the current checking tile. The range is stored in the system memory and printed on the checking tiles.



NOTICE

The **wave-scan 3** (7403) has one high-gloss sample included to test the instrument. The **wave-scan 3 dual** (7400) has two samples included – high gloss and semi-gloss.



4 Quick Measurements

With this function you can easily perform one or more measurements. For example: You can measure a standard and a sample probe and compare the results manually. Make sure the parameters are set – see [Measurement Parameters](#) [▶ 53].

4.1 Measuring

Click on icon **Quick check**. The **Quick check** screen is displayed – showing the first sample to be measured.

Quick check	
Sample 001 0/3	
du	- Wa -
Wb	- Wc -
Wd	- We -
DOI	- B -
LW	- SW -
<div> ☰ Vert Hor </div>	

The instrument is ready to measure.

4.2 Initial Menu

At this state the context menu contains the single option **End test series**.


Quick check	
Sample 001 0/3	
du	- Wa -
Wb	- Wc -
Wd	- We -
DOI	- B -
LW	- SW -
End test series	
<div> ☰ Vert Hor </div>	

Via this option you can go back to the main menu. This is also possible via the icon Back in the upper left.


4.3 Procedure

In **Quick check** mode perform the following steps:

1. Place instrument on first sample to be measured.
2. Press and hold the **Operate** button to measure the sample
3. Move the instrument evenly and slowly from the right to the left – or vice versa - over the sample's surface. During the measurement a progress bar is shown.




The sample is measured; the measured data is evaluated.



The results of the evaluation are shown in the display, see below.

4.4 Results

After successful measurement the result screen may look like this.




The items on the screen have the following meaning.

1 Name The name of the sample currently measured, see also Overview [► 35].	2 Statistics Measures taken and measures to be taken, see Statistics [► 55].
3 Scales Scales can be configured in the measurement parameters, see Scales [► 54].	4 Contextmenu Contains the measurement options currently available, see Final Menu [► 34].
5 Orientation Can be switched to the correct value, if required, see Orientation Detection [► 58].	

After required number of measurements on the current sample place instrument on the next sample and measure it.

4.5 Messages

Performing a successful measurement requires some practice. Error messages indicating the type of error may appear during the first trials.




The LED light on the instrument turns to red and a warn signal is given out, see [Configuration](#) [► 51] > **Sound**. Check the message and repeat.



NOTICE

Different messages are possible – depending on the current state of instrument or measurement, see [System Messages](#) [► 70].

4.6 Final Menu



The context menu now contains additional entries:

- **Delete last measurement:** Enables you to repeat the last measurement.
- **Delete sample:** Enables you to repeat all measurements on the current sample.
- **End test series:** Enables you to repeat the complete test series.
- **Interrupt statistics:** Interrupts the measurements on the current sample before reaching the preset number of measurements. Details see [Statistics](#) [► 55].
- **Save data:** This option is reserved for a later release.

You can continue to measure further samples or stop the quick check via the **Back** symbol.



NOTICE

In **Quick check** mode the measurements are not saved. If you go back to the dashboard, your measurement data is dropped. Use **Measure** mode to store data.

5 Standard Measurements

This function allows to perform various test series with different samples and variable amount of measurements. The results are stored automatically. If more than one measurement is done on a sample, statistics are evaluated. Make sure the parameters are set - see: [Measurement Parameters](#) [► 53].

Prerequisite: You are familiar with the [Quick Measurements](#) [► 31] mode.



NOTICE

Standards can be created in the instruments and can be downloaded from "smart-chart". Downloaded standards can not be deleted in the instrument, but only via the software.

5.1 Overview

You are able to manage your measurements as shown in the following example.

```
Standard 001
--- Test series 001
--- --- Sample 001
--- --- --- Measurement 1
--- --- --- Measurement 2
--- --- --- ...
--- --- --- Measurement n
--- --- Sample 002
--- --- ...
--- --- Sample n
--- Test series 002
--- ...
--- Test series n
...
Standard 2
...
Standard n
```

The objects listed above are to be administrated in the following way:

- **Standard:** Contains different **Test series**. Create and fill in **Measure** mode. Renaming is not supported. View and delete in **Browse** mode – only if filled with data.
- **Test series:** Contains different **Samples**. Create and rename in **Measure** mode. Delete in **Measure** mode or in **Browse** mode. View in **Browse** mode.
- **Sample:** Contains different **Measurements**. Create and rename in **Measure** mode. Delete in **Measure** mode. View in **Browse** mode. Number of **Measurements** see **Configuration > Measurement Parameters > Statistics**.
- **Measurement:** Contains different **measurements data**. Create and rename in **Measure** mode. Delete in **Measure** mode. View in **Browse** mode. Data displayed see **Configuration > Measurement Parameters > Scales**.

5.2 Measuring



Click on icon **Measure**. The list with existing standards is displayed.

Measure

ALTANA Blue

Arctic Blue

Royal Blue

Standard 001

Standard 002

Filter icon (+)

The items in the list can be filtered. Click on the filter icon.

Filter

Blue

Q W E R T Y U I O P

A S D F G H J K L

Z X C V B N M _ -

Up arrow, X, 123, Left arrow, Right arrow

Enter the filter criteria and click on the accept icon.

Measure

ALTANA Blue

Arctic Blue


Royal Blue

Filter icon (X) (+)


The list of items only contains the standard matching the filter criteria.

5.3 Standards

Select an existing **Standard** or create a new one – with the **Plus** symbol. You can use the default name or enter a new one.




After confirmation you can check and change the default measurement parameters for the current standard.



After confirmation you are ready to measure.

5.4 Test Series


After selecting an existing **Standard** the screen **Select test series** is displayed – in case of new standard the first test series is created automatically.



Select an existing **Test series** or create a new one – with the entry **Plus** symbol.

5.5 Samples


After creating a new **Test series** the measurement screen for **Sample 001** is displayed – in case of an already existing test series the next sample to be measured is displayed.



The instrument is now ready to measure.

5.5.1 Initial Menu

At this state the menu contains following options.



The available options are:

- **Sample - Edit:** You can rename the sample.
- **Test series – Edit:** You can rename the test series.
- **Delete test series:** Enables you to repeat all measurements in the current test series.
- **End test series:** Brings you back to the test series selection screen.


Use the pencil symbol to rename the objects according to your needs.




Now you can start measuring.

5.5.2 First Measurement

Perform the first measurement on the first sample. The procedure is the same as in the [Quick Measurements](#) [► 31] mode. During the measurement a progress bar is shown.



Afterwards the instrument calculates the results.




The results are shown in the display.

Black - 653212 - Test			
● Sample 001		1/2	
du	29.8	Wa	10.0
Wb	10.0	Wc	14.7
Wd	15.5	We	29.7
DOI	81.5	B	-6.4
LW	10.3	SW	39.6

You can now proceed with the next measurement.

5.5.3 Final Menu

After a successful measurement the menu contains following options.



The available options are:

- **Sample - Edit:** See above.
- **Test series – Edit:** See above.
- **Delete last measurement:** Enables you to repeat the last measurement.
- **Delete sample:** Enables you to repeat all measurements on the current sample.
- **Delete test series:** Enables you to repeat the complete test series.
- **End test series:** Enables you to stop the current test series. You can continue later.
- **Interrupt statistics:** Interrupts the measurements on the current sample before reaching the preset number of measurements. Details see [Statistics](#) [► 55].

Perform the next measurement and all other required measurements on the first sample.

5.5.4 Next Measurement

When all measurements according to the current statistics settings are done, the next measurement will be automatically assigned to the next sample.

← Black - 653212 - Test			
● Sample 001		2/2	
du	31.3	Wa	9.9
Wb	10.1	Wc	15.1
Wd	15.5	We	30.7
DOI	80.7	B	-6.3
LW	10.3	SW	40.2
<div> <div></div> <div>Vert</div> <div>Hor</div> </div>			

Proceed with the following steps:

- Perform the next measurement until the current sample is completed.
- Measure the next sample until the current test series is completed.
- Repeat this procedure for all other test series until the current standard is completed.

← Black - 653212 - Test			
● Sample 002		1/2	
du	34.3	Wa	10.1
Wb	9.7	Wc	14.6
Wd	15.3	We	29.4
DOI	78.9	B	-6.5
LW	10.6	SW	39.7
<div> <div></div> <div>Vert</div> <div>Hor</div> </div>			

You can now proceed with the next standard to be measured.

5.6 Aborting

You can abort the measurement procedure at any time via the menu option **End test series** and return later to continue.



NOTICE

The modus **Measure** always shows the next measurement to be done. If you want to view or manage results, please use the **Browse** function in the main menu.



6 Organizer Measurements


The instrument can be connected to the software suite "smart-chart". Using the software standards and organizers can be downloaded into the instrument.

Measurement results can be uploaded and evaluated later on. Organizers contain complex series of measurements and help you to organize your measurement process.

6.1 Organizer Files


Definition of Check Zones

Depending on the application, the system can be used in various ways, from single measurements in R&D up to routine quality control procedures (e.g. automobile industries).



In order to guarantee a flexible data analysis, it is essential to allocate the data to a clearly defined object (identification).

Checkzones



Download to Instrument


An organizer file clearly defines the object to be measured. The organizers need to be created in the software "smart-chart".



Each organizer defines the measurement sequence (sampling procedure). This file is transferred to the instrument. It is used to guide you as the user during the measurement procedure.

6.2 Organizer Process

If at least one organizer file has been downloaded into the instrument, the corresponding icon appears in the main menu.



Clicking this icons displays the list of organizers in the instrument.




Organizer

C250 TDi Black 2019

HURACAN BODY

Test Organizer 2019

By using this organizer all required check zones can be clearly identified.



Organizer

● Hood L 3/3

SW	41.2	LW	9.9
DOI	-	du	32.5
Wa	10.2	Wb	9.6
Wc	15.3	Wd	14.1
We	30.5		

Vert Hor

In the example shown above each check zone requires three measurements. With the next measurement the following check zone in the organizer will be selected automatically. This allows fast processing of all check zones defined in an organizer file.

6.3 Upload to Database

The saved results are transferred to the PC and displayed as a QC report. The data is saved in a database for further analysis over time. Pre-prepared test reports in the software “smart-chart” assist in analyzing the data.

Storage Structure

Each measurement series contains a header and the individual measurements with their name (check zone) and the measured values.

Test Report

Scorecard

Trend

Table

Schematic

Line

Balance / Spectrum

☒ Spectrum
 ☐ Tolerances

Instrument

Date

Model

Color

Paintline

Comment

Serial no.

wave-scan

10.07.2019

Combi FIS 003

Yulong Glacier NAK 2 070217

RL

Checkzone ^

Date

Status

SW

LW

DOI

du

Wa

Wb

Wc

Wd

We

B

Match to Standard

Door LF

7/10 1:36:02 PM

==

13,7

5,5

83,1

25,2

13,0

19,5

12,2

14,9

10,7

-2,8

Door LR

7/10 1:36:02 PM

==

12,6

6,0

84,0

23,8

13,0

18,8

11,2

16,9

16,6

-3,4

Door RF

7/10 1:36:02 PM

==

19,2

8,3

84,9

21,9

8,1

19,4

13,3

20,7

14,6

-3,8

Door RR

7/10 1:36:02 PM

==

21,7

9,2

84,8

21,5

9,4

21,4

13,7

22,2

14,2

-3,4

Fascia LF

7/10 1:36:02 PM

==

24,9

8,3

80,3

27,2

17,8

30,8

16,3

21,4

13,3

-0,3

Fascia RF

7/10 1:36:02 PM

==

27,8

7,0

82,2

24,5

12,0

27,2

12,7

18,2

13,5

-0,8

Hood L

7/10 1:36:02 PM

==

24,8

5,9

79,9

28,0

19,7

31,0

14,9

14,5

13,5

1,6

Hood R

7/10 1:36:02 PM

==

36,4

10,3

79,0

25,9

19,6

39,7

19,3

21,7

14,2

2,4

Quater LR

7/10 1:36:02 PM

==

12,1

6,0

83,1

25,1

12,2

20,1

12,8

16,1

13,7

-2,8

Quater RR

7/10 1:36:02 PM

==

25,7

6,6

84,1

21,0

10,3

26,5

11,5

18,1

16,7

-1,0

Roof

7/10 1:36:02 PM

==

13,9

2,7

83,3

24,5

14,3

20,8

8,6

10,1

9,1

-0,9

Trunk

7/10 1:36:02 PM

==

30,3

7,1

83,1

21,7

10,8

29,6

13,2

18,0

14,6

0,0

In the header, up to 5 parameters can be defined for object identification, for example:

- 1: Model
- 2: Color
- 3: Paint line
- 4: Comment
- 5: Vehicle-ID

Parameters #1 to #3 are defined in the organizer file, parameters #4 and #5 can be entered before storage in the database. Additionally, date and time of the measurements are stored.

This structure determines the data organization in the instrument and in the database. In addition to the definition of parameters **before** the measurements using organizers, the parameters and check zones can also be entered **during** the measurements – see [Standard Measurements](#) [► 35].



7 Browse Measurements


Measurement data and objects can be viewed and deleted directly at the instrument and in "smart-chart". Below the administration at the instrument is described.

The **Browse** function allows you to view your existing measurements and to delete existing **Standards** and / or **Test series**, if necessary.


Prerequisite: At least one measurement is stored.

7.1 View Data

Click on icon **Browse**. The list with all types of measurements is displayed.



Click on the desired measurement type, e.g. on **Measure**. The list with all dedicated measurements appears.



Click on the desired object. The list with all dedicated test series appears.



Click on the desired test series. The details for this measurement appear. Now you can view the samples measured in this test series.

Testserie 002			
Sample 002			
du	33.2	Wa	10.3
Wb	10.1	Wc	15.4
Wd	14.2	We	32.3
DOI	79.6	B	-6.2
LW	9.8	SW	36.6

You can turn the item "Sample xxx" to the left and to the right. For each sample the average data is displayed. Scroll down to view the statistical data.

Testserie 002			
Sample 002			
	Min	Mean	Min
du	32.2	33.2	32.2
Wa	10.3	10.3	10.3
Wb	9.8	10.1	9.8
Wc	14.7	15.4	14.7
Wd	13.0	14.2	13.0
We	32.1	32.3	32.1


This can be activated under [Configuration](#) [► 51] > [Measurement Parameters](#) [► 53] > [Statistics](#) [► 55].

7.2 Delete Data

You can delete complete measurements and/or complete test series.

Delete Measurement

To delete a complete measurement, select it from the list. You can also make a multi-selection here.



Click on the **Trashcan** icon. A confirmation message is displayed.



Confirm with the checkmark. The measurement is deleted.

Delete Test Series

To delete a complete test series, select it from the list. You can also make a multi-selection here.



Click on the **Trashcan** icon. A confirmation message is displayed.




Confirm with the checkmark. The test series is deleted.

8 Configuration




With this function you can configure the system according to your needs. There are different types provided to change the configuration of the system.

Click on icon **Configuration**. The configuration screens provide buttons for easy navigation. The current settings can just be viewed or changed and saved.




Some options can be activated via a so-called toggle button. Some options can be configured via a rotating menu – which is working like a wheel.



These options have following meaning.

- | | |
|--|---|
| 1 Back: Go back to previous screen. | 2 Cancel: Go back to previous screen without saving. |
| 3 Accept: Go back to the previous screen and save your changes. | 4 Active: Option is activated. Click left to deactivate. |
| 5 Inactive: Option is deactivated. Click right to activate. | 6 Wheel: Tap an entry in the menu and move it to the left or to the right. |
| 7 Left: One step to the left moves the wheel to next value. | 8 Right: One step to the right moves the wheel to previous value. |

The configuration screen consists of an upper and a lower part. You can slide the screen to the bottom and back to the top to view the options available.




These options have following meaning.

1 Measurement Parameters: See Measurement Parameters [► 53].	2 WiFi: Establish a WiFi Connection [► 59] here.
3 Language: Set instrument language here.	4 Date / time: Set system time, time zone and daylight saving time here.
5 Color scheme: Adjust screen brightness to day and night conditions here.	6 Information: Shows system, network and legal information. See System Information [► 61].
7 Sound: Activate or deactivate the internal beeper here – useful for pass-fail measurements.	8 Display time: Define the interval for automatic shutdown here. See Display Time [► 61].
9 Checking tiles: Add your Checking Tiles [► 62] to the system memory.	10 Factory reset: Reset instrument to factory settings here. See Factory Reset [► 63].
11 Protect configuration: Password is required to open the configuration screen. See Protect Configuration [► 64].	12 Shutdown: Perform manually switch off to save battery power or replace battery pack here. See Shutdown [► 65].

8.1 Measurement Parameters

Via this function you can configure how the measurements are to be done.



These options have following meaning.

- | | |
|---|--|
| <p>1 Scales: Selected scales are displayed after measurement. See Scales [► 54].</p> | <p>2 Statistics: No. of readings to be taken per sample. Statistics are evaluated, if $n > 1$. See Statistics [► 55].</p> |
| <p>3 Scan length
Distance the device is to be moved to complete a measurement. See Scan Length [► 56] Statistics [► 55].</p> | <p>4 Plausibility
Compares corrected and uncorrected measurement value. See Plausibility [► 56].</p> |
| <p>5 Interrupt statistics: Test series can be interrupted before reaching the defined no. of readings. See Interrupt Statistics [► 58].</p> | <p>Orientation detection: Automatically detects orientation of device – vertical or horizontal. See Orientation Detection [► 58].</p> |

To set measurement parameters:

1. Click on the parameter you want to set. The list with selectable parameters appears.
2. Choose the required parameter and confirm by clicking on the check mark in the upper right corner.
3. Repeat this procedure until all your desired parameters are set.
4. Confirm by clicking on the checkmark in the upper right corner.




NOTICE

If you change the measurement parameters – e.g. the no. of measurements – these changes become valid for new configurations / test series. Existing objects will not be changed.

8.1.1 Scales

Via this function you can decide, which data is to be displayed in the measurements results.



Scales	
Structure Spectrum	
<input checked="" type="checkbox"/>	du
<input checked="" type="checkbox"/>	Wa
<input checked="" type="checkbox"/>	Wb
<input checked="" type="checkbox"/>	Wc

Following entries are default scales:

- Dullnes (du)
- Wavelength – Range A (Wa)
- Wavelength – Range B (Wb)
- Wavelength – Range C (Wc)
- Wavelength – Range D (Wd)
- Wavelength – Range E (We)
- Longwave (LW)
- Shortwave (SW)
- Structure Balance (B)

All other scales are project-specific. Consult your project documentation for more information.



NOTICE

Measurement data will be saved for all scales. The selection of scales has no impact on the data to be saved – it just toggles the display of a scale while measuring.

8.1.2 Statistics

If the number of measurements is set to a value greater than 1, statistics values are shown in the display after measurement.

Statistics	
n Sample	2 3 4
Column 1	Off Min Max
Column 2	Min Max Stdev
Column 3	Value Mean Off

You have following options:

- **n Sample:** Defines how many measurements are to be taken.
- **Column 1 .. 3:** For each column you can decide, which value is to be displayed.

The statistic function comprise following data:

- **Off:** Column w/o data
- **Min:** Minimum value
- **Max:** Maximum value
- **Stdev:** Standard deviation
- **Range:** Measurement interval
- **Value:** Actual value
- **Mean:** Arithmetic average




NOTICE

To switch off statistics you have to set if **n = 1**. To save this setting it is required, to set all columns to **Off**.

8.1.3 Scan Length

You can define the distance the device is to be moved across the surface of the sample in order to complete a measurement.



You have following options:

- **5cm**
- **10 cm**
- **20 cm**



NOTICE

The selected scan length has impact on measurement accuracy. Using a short scan length will result in strong statistical skewing of measurement values for large wavelengths. Thus, when using the Wd scale with a scan length of 5 cm, at least 3 measurements should be made per sample to ensure representative values.

8.1.4 Plausibility

Defects on the sample surface, such as scratches or craters, can cause major errors in measurement values. The instruments automatically corrects these errors: The affected scan areas are cut out and the measurement values are calculated from the corrected data.


If **Plausibility** is active, the instrument compares the corrected and uncorrected measurement value. The greater the difference between the corrected and uncorrected data, the more critical is the surface defect.




NOTICE

If the difference is greater than 20%, the measurement will be evaluated as a faulty measurement and an error message appears. In this case a new measurement is needed.

The following image shows the measurement range, if **Plausibility** is inactive (switched off).




The following image shows the measurement range, if **Plausibility** is active (switched on).



As shown in the images the measurement range can be expanded by activating the option **Plausibility**.

8.1.5 Interrupt Statistics


If this option is activated, the corresponding entry appears in the context menu during measurements.



By selecting this entry during measurements you can interrupt the measurements on a sample before reaching the number of measurements set in the statistics.

8.1.6 Orientation Detection


If activated the instrument automatically detects the current orientation of the device – vertical or horizontal – during the measurements.



The result of the detection is shown in the measurement screen. You can also alter the orientation manually by selecting **Vert** or **Hor**.


8.2 WiFi Connection

The instrument is equipped with a WiFi adapter. You can use the WiFi connection alternatively to the USB connection. To connect to a WiFi network click on the WiFi symbol.




A dialog box titled "Select your country" with a close button (X) on the left and a checkmark on the right. It contains two radio button options: "Germany" (selected) and "- Other -".

Select your country and accept to continue.



A screen titled "WiFi setup" with a back arrow on the left and a toggle switch on the right. The toggle switch is currently turned off. Below the title, it says "Not connected". Underneath, there is a section titled "Available networks" which currently displays "No networks available".

Activate the WiFi toggle button and select the desired network from the list. By clicking on the line showing **Not connected** or **<Network-Name>** you can decide to activate or deactivate the **DHCP** option.



A dialog box titled "DHCP setup" with a close button (X) on the left and a checkmark on the right. It contains a toggle switch labeled "DHCP Off/On", which is currently turned on.

If the **DHCP** option is inactive, you can enter the IP details for the WiFi connection manually. Click a line to enter the corresponding data.

× DHCP setup ✓

DHCP Off/On ☒

IP Address: 192.168.0.128

Subnet: 255.255.255.0

Gateway: 192.168.0.1

DNS: 192.168.0.1

Accept your changes to enter the WiFi key – required if the network is secured.

× Enter WiFi key ✓

7	8	9	%	@	!	:	()	
4	5	6	<	>	.	,	+	-	
1	2	3	?	&	\$:	*	/	
0	⌫						Abc...	⬅	➡

The instrument connects to the network. A confirmation message is displayed.

Please confirm... ✓

WiFi connection
successful!

Accept the message. You are connected to the network. In the dashboard the WiFi symbol is shown indicating the current field strength. To disconnect from network, switch the WiFi option off in the WiFi configuration screen.

8.3 System Information

Via this menu entry you can view the details about your instrument.



Information	
Instrument	
Serial no.	15790116
Catalog no.	7400
Firmware version	1.0.0.0
Bootloader version	0.0.1.0
Certification date	1999.12.31


Following data is displayed:

- Serial Number: The unique ID of your instrument.
- Catalog Number: The order number in our products catalog.
- Firmware Version: The current version of the system software.
- Certification Date: The date of the last certification. A re-certification by BYK-Gardner should take place once a year.
- Network data like MAC or IP address: Only relevant in case of active WiFi connection.

In case you contact your local BYK-Gardner service center please have these data handy.

8.4 Display Time


You can configure the time interval for the automatic shutdown of your instrument.



Following values are possible (in minutes): 1, 2, 5, 10, 15, 30.


8.5 Checking Tiles

In order to document the correct measurement status of your instrument you can save the checking tiles in the system memory. Select the option **Add to standard list**.



The screenshot shows a menu titled 'Checking tile' with a back arrow. Below the title is an 'Information' section. There are two entries, 'Checking tile 1' and 'Checking tile 2'. Each entry has a corresponding 'Add to standard list' option below it.

The option **Add to standard list** is active, if the checking tile has not been added yet. In order to delete these entries from memory use the function [Browse Measurements \[► 47\]](#) > **Standards**.



The screenshot shows a confirmation dialog box with a blue header bar containing the text 'Please confirm...' and a checkmark icon. The main area of the dialog box displays the text '1 Check 11 added to standard list'.

Now you can use the function [Standard Measurements \[► 35\]](#) to check the tolerances. Details see [Testing the Instrument \[► 30\]](#).

If the differences are within your tolerances you can continue to measure with your instrument. Otherwise clean the standards and repeat, see [Cleaning Instructions \[► 68\]](#).



NOTICE


All measurements on the checking tiles are stored in the instrument. Transfer the measurement data to "smart-chart" to document each test case performed.

8.6 Factory Reset

If you are having technical problems with your instrument, you can perform a fallback to the factory settings.




Confirm the security message to perform the fallback. You have to enter the password "byk-instruments" – see also section Technical Data > General Data.



After fallback all your personal configuration and measurement data in the device will be lost. The instrument starts in a fresh state.

8.7 Protect Configuration

You can protect the current configuration of your instrument via password against accidental or intentional changes. Select **Protect configuration**.



Activate the option. You have to enter a password. The password is shown in clear text during input. There is no 2nd confirmation input of password required.




If the option is activated the **Configuration** menu can only be accessed from the dashboard by entering the password.

Note down the password on a secure place – if you do not remember, you will have to contact your local BYK-Gardner certified service center to get the master password.

8.8 Shutdown

The instrument is switched off automatically after the time interval configured, see [Display Time](#) [► 61].

Select **Shutdown** to switch off the instrument manually – e.g. before you remove the rechargeable battery pack.



The instrument switches off after confirmation.

9 Appendix

9.1 Application Hints

This section lists the common measurement tasks and the recommended procedure.

Single Measurements

For occasional sample-measurements:

- Take readings, see chapter [Quick Measurements](#) [► 31].
- Transfer results directly to smart-chart.

Objects with several Test Zones

Here test sequence / identification can be standardized, e.g. automobile or add-on parts:

- Generate organizer in smart-chart.
- Transfer organizer to the instrument.
- Take readings, see chapter [Organizer Measurements](#) [► 43].
- Transfer results to smart-chart and store in data base.
- Perform data analysis in smart-chart.

Regular Test eries

Here test sequence / identification can be standardized, e.g. batch control:

- Same procedure as for task #2.

Occasional Test Series

Here test sequence / identification can not be standardized, e.g. projects:

- Generate new measurement configuration.
- Take readings, see chapter [Standard Measurements](#) [► 35].
- Transfer results directly to smart-chart.

9.2 Cleaning Instructions

For a professional cleaning of your instrument see:

- www.byk-instruments.com/preventive-maintenance

Safety Instructions



⚠ CAUTION

Before cleaning, the instrument and accessories must be disconnected from the power supply as described in the [Safety Instructions](#) [▶ 6].



⚠ WARNING

Do not insert any objects into the measurement aperture for cleaning. The instrument could get damaged - affecting a proper and safe operation.



⚠ WARNING

Do not use any acetone! The instrument housing is resistant to a number of solvents, but cannot be guaranteed to withstand all chemicals. You should therefore use a soft, moist cloth for cleaning. For cleaning excessive dirt, use propanol.

Cleaning the Instrument

A cleaning mat to clean the wheels measurement unit is situated on top of the cover for the reference tiles.



To clean the wheels roll the measurement unit several times over the blue mat and then over a clean sheet of paper. Dirt will stick to the mat and can be removed with clear water.



Check if the cleaning was sufficient and repeat the procedure if required.

Cleaning the Test Tiles



WARNING

Do not use any acetone! The accuracy of the measurement can be significantly impacted by using dirty or damaged standards.

Since the surfaces of the standards are highly sensitive, cleaning must be undertaken with great care.

To clean standards, use a new lint-free cloth, dust-free lens paper or an optical cloth.

Apply only slight pressure as you clean and make certain there are no large particles stuck in the cloth that could damage the surface.

For dirt that is difficult to remove, use an optical cloth dipped in liquid. Then wipe the surface with a dry optical cloth.



NOTICE


Exact calibration is not possible unless the standard is in perfect condition. If the condition of the standard seems doubtful because of its appearance or measurement errors, we will be happy to check it for you.

9.3 System Messages

If an error occurs, the display will indicate the error type. Confirm by pressing the button **Operate**.

Acceleration

The instrument was accelerated too fast across the sample or the scan direction was changed too fast. Repeat the measurement.



Scan Length

The required scan length has not been reached completely. Repeat until a short audio confirmation is heard. Small areas can be measured by moving the instrument back and forth.



Speed

You have moved the measurement unit too quickly or unevenly over the sample. Repeat the measurement.




Low Battery

The rechargeable battery pack has insufficient capacity left to power the instrument. Charge or replace battery pack.




Infrared Laser

The infrared laser in the instrument is not working correctly. Repeat the measurement. If the error remains try cleaning the instrument. If this does not help, contact your local service center.




Measurement Timeout

The device stopped for more too long. Repeat the measurement.



Linear Range - Dullness

The measurement was performed on a surface with low image forming qualities.



High Dullness

The measurement was performed on a too matt surface.



Dull Surface

The measurement was performed on a too matt surface.

**NOTICE**

No measurement values can be displayed.

Linear Range - Steep Slope

The measurement was out of the linear range.



Steep Slope

The measurement was performed on a surface with steep structure slopes.



Very Steep Slope

The measurement was performed on a surface with very steep structure slopes.



NOTICE

Attention: Samples with different image forming quality are not comparable!

9.4 Technical Data

Measuring Data

Light Source	Laser Diode LED and IR-SLD
Laser Diode	Laser Class 1, $P \leq 390 \mu\text{W}$, $\lambda=670 \text{ nm}$, DIN EN 60825-1:2015-07
Measure Range	wave-scan 3: High-Gloss Surfaces ($du < 40$, linear range) wave-scan 3 dual: High to Semi-Gloss ($du < 65$, linear range)
Structure Spectrum	du: $< 0,1 \text{ mm}$ Wa: $0,1 \text{ to } 0,3 \text{ mm}$ Wb: $0,3 \text{ to } 1,0 \text{ mm}$ Wc: $1,0 \text{ to } 3,0 \text{ mm}$ Wd: $3,0 \text{ to } 10,0 \text{ mm}$ We: $10,0 \text{ to } 30,0 \text{ mm}$
Scan Length	5 cm 10 cm 20 cm
Repeatability	$du < 40$: 4% or > 0.4 (standard deviation) $du > 40$: 6% or > 0.6 (standard deviation)
Reproducibility	$du < 40$: 6% or > 0.6 (standard deviation) $du > 40$: 8% or > 0.8 (standard deviation)
Object Radius	$> 500 \text{ mm}$
Smallest Sample Size	35 mm x 150 mm
Resolution	375 pixel per cm
Battery Capacity	Up to 4000 readings - depending on duty cycle and display-on time
Memory Capacity	10000 readings 4000 standards 1000 test series 50 organizers

Charging Data

Rechargeable Battery Pack	3,6 V DC; 2350 mAh; 8,46 Wh
Charging	4,2 V DC; max. 2,0 A
Docking Station	Power Supply: 12 V DC; max. 2,0 A (Power Supply) 5 V DC; max. 0,5 A (USB-B) Dimensions (LxWxH): 205 x 78 x 88 mm Weight: Ca. 800 g
Power Supply	Input: 100 - 240 V AC; 50/60 Hz ; 800 mA Output: 12 V DC; 2,5 A Dimensions (LxWxH): 50 x 100 x 33 mm Weight: Ca. 180 g

General Data

Temperature Range	10° C to 40° C for operation 0° C to 60° C for storage
Rel. Humidity	Up to 85% non-condensing at 35° C
Weight	Ca. 700 g
Dimensions (LxWxH)	147 x 111 x 69 mm
Password for Factory Reset	byk-instruments
Interface	USB 2.0

You can find more details about our products on our website:

- <https://www.byk-instruments.com>

9.5 Global Services

Besides the repair of your instrument we offer the following additional services.

First Diagnosis on the Telephone or by E-mail

Call us or send us an e-mail and we will try to solve your problem. If this is not successful, please send us the instrument for repair.

Preventive Maintenance, Calibration, and Recertification

For precautionary reasons we recommend regular preventive maintenance. We carry out this preventive maintenance automatically when you send us your instrument for maintenance and recertification.

We clean the optics, check all functions, test and, if required, adjust the measured values by using reference standards.

You will receive a certificate, which can be retraced to international standards. Details see:

- www.byk-instruments.com/technical-services

Provisioning of Loaners

During the period of repair we furnish you with a loaner on request and availability.

Maintenance Agreement

In case you want to make sure that the necessary maintenance is being done on a regular basis and on time, we recommend a maintenance agreement.

Extended Warranty Contracts

Furthermore, you can request an extended warranty contract for additional 12 months. Ordering Information:

- SE-4840 Extended Warranty

9.6 Service Points



BYK-Gardner global service centers with ISO / IEC 17025 accredited laboratories

Headquarter Germany c/o BYK-Gardner GmbH Lausitzer Strasse 8, 82538 Geretsried, Germany	Headquarter USA c/o BYK-Gardner USA 9104 Guilford Rd., Columbia, MD 21046, USA	Headquarter PTE c/o BYK USA dba Paul N. Gardner 316 N.E. First Street Pompano Beach, FL 33060 - 6608, USA
BYK-Gardner Service Point Austria, Hungary, Slovenia c/o Friedrich W. Bloch GmbH Wagramerstrasse 201, 1210 Vienna, Austria	BYK-Gardner Service Point France c/o Eckart France S.A.S. 31 Rue Amilcar Cipriani 93400, Saint Ouen, France	BYK-Gardner Service Point Spain c/o Actega Artística S.A.U. Calle Balmes 8, Suite: 3º 2ª, 08291 Ripollet, Spain
BYK-Gardner Service Point UK and Ireland c/o BYK Additives Ltd. 450 Bath Road, Longford, Heathrow, UB7 0EB, United Kingdom	BYK-Gardner Service Point South Latin America c/o MAST Comercial e Importadora LTDA Rua Itaporanga, 340-B, Bairro Paraíso, Santo André - SP, 09190-640, Brazil	BYK-Gardner Service Point China c/o BYK (Tongling) Co. Ltd. Shanghai Branch Block 6A, Building A, No 88 Hong Cao Road, Xuhui District, Shanghai 200233, P.R. China
BYK-Gardner Service Point India BYK India Pvt. Ltd. 147, Mumbai - Pune Road 411018 Pune Maharashtra, India	BYK-Gardner Service Point Japan c/o Tetsutani Co. Ltd. Chuo-ku, Osaka, Tokui cho 2-2-2, Japan	
Complete list: https://www.byk-instruments.com/global-service-centers		

Index

A

Acceleration 70

B

Balance 54
 Battery 28
 Low 27, 71
 Pack 24
 Battery Pack
 Charge 25
 Exchange 25
 Browse 47

C

Calibration 30, 76
 Catalog Number 61
 Certificate 15, 76
 Certification Date 61
 Charge
 Battery Pack 25
 Checking 30, 62
 Cleaning 68
 Configuration 51
 Conformity 11
 Correction 56
 Cover
 Protection 16

D

Data
 Save 34
 Declaration 11
 Delete
 Measurement 34, 41
 Sample 34, 41
 Delete data 49
 Detection
 Orientation 58
 Display
 Flip 29
 Display Time 61
 Download 20
 Dullnes 54
 Dullness 72

E

Edit
 Sample 41
 Test Series 41
 End

Test Series 34, 41
 Error 33, 70
 Exchange
 Battery Pack 25

F

Factory Reset 63
 Fallback 63
 Firmware Version 61
 Flip
 Display 29

G

Global Service Centers 77

H

Hand strap 27

I

Inclination
 Sensor 29
 Information
 System 61
 Installation 21
 Interrupt
 Statistics 34, 41
 Interrupt Statistics 58
 IR Laser 71, 72
 ISO / IEC 17025 77

L

Laser
 Infrared 71, 72
 LED
 Instrument 33
 Power 26
 Linear Range 72
 Loaner 76
 Longwave 54
 Low Battery 27, 71

M

MAC Address;IP Address 61
 Main Menu 28
 Maintenance 76
 Master Password 64
 Measurement
 Delete 34, 41
 Timeout 71
 Menu 33, 34

Main	28
Message	33, 70
Movement	
Timeout	71

N

Navigation	51
------------	----

O

Orientation	33
Orientation Detection	58

P

Password	63, 64
Plausibility	56
Power	28
LED	26
Protection	64
Cover	16

Q

Quick Check	31
-------------	----

R

Range	
Linear	72
Recertification	76
Repair	76
Reset	63

S

Sample	
Delete	34, 41
Edit	41
Save	
Data	34
Scales	33, 54
Scan Length	56, 70
Serial Number	61
Service Points	77
Services	76
Settings	51
Shortwave	54
Shutdown	23, 24, 61, 65
smart-chart	23
smart-process	20
Software	20
Speed	70
Statistics	33, 55
Interrupt	34, 41, 58
Steep Slope	73
Strap	27
System	51

Information	61
System Time	28

T

Test series	
Delete	34, 41
Edit	41
Testing	30, 62
Time	28
Display	61
Timeout	
Measurement	71
Movement	71
Toggle	51

V

Version	20
View data	47

W

Warranty	76
Wavelength	54
Wheel	51
WiFi	28, 59
Worldmap	77
Wrist strap	27

Notes

[illegible]

Download your software from:
<https://www.byk-instruments.com/software>

Download your manual from:
<https://www.byk-instruments.com/manuals>

Find more information on our products and services:
<https://www.byk-instruments.com>

301 200 085 E 2011